

## Karta výrobku RSSM1018C3RD

---



|                         |                 |
|-------------------------|-----------------|
| <b>Symbol:</b>          | RSSM1018C3RD    |
| <b>Skupina výrobků:</b> | Rocker Switches |

### Parametry výrobku

|                                  |                |
|----------------------------------|----------------|
| <b>Type of switch:</b>           | ROCKER         |
| <b>Contacts configuration:</b>   | SPST           |
| <b>Number of positions:</b>      | 2              |
| <b>Stable positions number:</b>  | 2              |
| <b>Switching method:</b>         | ON-OFF         |
| <b>AC contacts rating @R:</b>    | 6.5A / 250V AC |
| <b>Key button colour:</b>        | red            |
| <b>Illumination:</b>             | neon lamp      |
| <b>Backlight colour:</b>         | red            |
| <b>Max. contact resistance::</b> | 35mΩ           |
| <b>Body colour:</b>              | black          |
| <b>Leads:</b>                    | connectors     |
| <b>Leads dimensions:</b>         | 4.8x0.8mm      |
| <b>Electrical life:</b>          | 10000 cycles   |

|                                |            |
|--------------------------------|------------|
| <b>Mounting hole diameter:</b> | Ø20mm      |
| <b>Button marking:</b>         | O-I        |
| <b>Shape:</b>                  | round      |
| <b>Operating temperature:</b>  | -30...80°C |

## Doplňková informace

|                         |             |
|-------------------------|-------------|
| <b>Hmotnost brutto:</b> | 0.005108 kg |
|-------------------------|-------------|