

| | |
|---|---|
| **Symbol:** | RSSM101A2C3BU |
| **Product groups:** | Rocker Switches |

# Product specifications

| | |
|---|---|
| **Type of switch:** | ROCKER |
| **Contacts configuration:** | SPST |
| **Number of positions:** | 2 |
| **Stable positions number:** | 2 |
| **Switching method:** | ON-OFF |
| **AC contacts rating @R:** | 3A / 250V AC |
| **Key button colour:** | blue |
| **Illumination:** | neon lamp |

| | |
|---|---|
| **Backlight colour:** | blue |
| **Max. contact resistance::** | 35mΩ |
| **Body colour:** | black |
| **Leads:** | connectors |
| **Leads dimensions:** | 4.8x0.8mm |
| **Electrical life:** | 10000 cycles |
| **Mounting hole dimensions:** | 19.2x13mm |
| **Button marking:** | O-I |
| **Shape:** | rectangular |
| **Body dimensions:** | 18.8x12.9x14.4mm |
| **Height above panel:** | 5.8mm |
| **Operating temperature:** | -30...80°C |
| **Related items:** | RSC07 |

# Additional information

| | |
|---|---|
| **Gross weight:** | 0.004 kg |